

Playskool MSA Rollbar Fitting Instructions

Firstly please check to make sure everything is in your kit, you should have:

- 1 - Big Black Rollbar
- 2 - Gold coloured rollbar inserts
- 4 - Long 10mm Bolts
- 4 - Short 10mm Bolts
- 2 - Short 8mm Bolts

The first thing to do is with some masking tape or gaffer tape, slide the gold anodized inserts into the rollbar and tape these into position.



Next place the rollbar onto the car. If you then bolt down the front half, this might require you to use a screwdriver to persuade the bar into position to line the bolts up.



The Short 10mm bolts will go through the holes that size and the 2 x 8mm bolts will go through the holes their size. Below is what it should look like, with the one bolt upside down to the rest on the passenger side. Also taking care when fitting the rollbar that the seat belt eyelets don't catch the rollbar (particularly on the passenger side).



The Gold anodized parts need to be bolted into place on the U brackets that are welded to the chassis, using two of long 10mm bolts.



Finally the gold anodized tubes need to be bolted to the rollbar. To do this it is easiest to do it on the car. With the car in the air and the rear wheels off, if you pilot drill a hole going diagonally through the centre of bar so when it comes out of the other side it misses the fuel tank. This then needs to be drilled with a 10mm drill so the bolts will go through. If you prefer you can remove the rollbar to do this.

That should be your rollbar fitted.